## **RESET BIOS**

AFTER RESETING THE BIOS YOU WILL NEED A COMPUTER KEYBOARD AND A COMPUTER MONITOR TO GET THE SYSTEM RUNNING AGAIN.

HAVE THESE ITEMS BEFORE RESETING YOUR SYSTEM,

TO RESET THE BIOS ON THE SYSTEM YOU MUST MOVE THE 3 PIN JUMPER WHICH IS USUALLY LOCATED NEAR THE LITHIUM BATTERY.

## YELLOW BOARD



**CLR\_CMOS** 

## RED BOARD



**J14** 

## WITH THE POWER OFF:

- MOVE THE JUMPER FROM ITS CURRENT POSITION (1-2) TO THE 2-3 POSTION.

THE BIOS IS NOW RESET TO FACTORY DEFAULTS.
YOU MUST NOW SET THE BIOS CONFIGURATIONS USING YOUR KEYBOARD AND MONITOR.
CONTINUE ON TO "SETTING BIOS" ON THE NEXT PAGE.

